

FieldSmart® Fiber Scalability Center (FSC)

Accessories



Ground/Locate Box


Description

The FieldSmart FSC Ground/Locate Box allows the ability to ground distribution cables without jeopardizing risk of damage to live circuits in cabinet. Often this task is outsourced and entry into the cabinet is not desired. The ground/locate box top allows an individual to access ground lugs from outside of the cabinet without risking internal damage to the fiber plant. The locate box is factory installed and must be ordered at the time of cabinet configuration. Dimensions: 7" H x 8" W with a 1" recess.




Pre-Configured Part Numbers


Part Number	Description
008829	Assembly, box, ground, FSC 288-576



External View



Inside Cabinet View




Full Cabinet View

Cabinet Security Strap

Description

The FieldSmart FSC Cabinet Security Strap provides additional security to prevent unauthorized access to pad and vault mount FieldSmart Cabinets, while still permitting access to service technicians for maintenance. It has a hinged locking brace that attaches to a full panel mount bracket. The lock hole is designed to accommodate a round security lock.



Pre-Configured Part Numbers

Part Number	Description
FMA-H5Z-SUB	FieldSmart FSC 288-PON, 432 cross-connect, hub collapse cabinet security strap