


# FieldSmart® Fiber Crossover Distribution System (FxDS) Accessories



## Staging Plate Trough

### Description

Troughs are an integral part of the FieldSmart fiber management platform. When used properly, troughs provide a protected route path then running jumpers between equipment. The Staging Plate Trough has two staging plates equipped with 36 positions each for “parking” optical splitter legs until they are ready to use.





### Pre-Configured Part Numbers

| Part Number | Description  |
|-------------|--|
| FMA-XXX-41  | FieldSmart FxDS Staging Plate Trough, 5" x 19" (127.00 mm x 482.60 mm) |

## Slack Management Panel

### Description

This panel mounts in either 19" or 23" (482.60 mm or 584.20 mm) frame and stores excess jumper length in a 1RU (1.75"; 44.45 mm) drawer based panel. It contains bend-radius spools for incremental and horizontal slack take up. When closed, the drawer protects fiber from accidental damage. The panel accommodates varying lengths of horizontal slack take up for up to 48, 3 mm jumpers.



### Pre-Configured Part Numbers

| Part Number | Description                                      |
|-------------|--|
| FMA-G11     | Slack management panel for 19" (482.60 mm) frame |
| FMA-G21     | Slack management panel for 23" (584.20 mm) frame |