

YOURx-Terminal Accessories-



Top Mount Bracket Kit for YOURx-Terminal

Description

Bracket mounts to cover, allowing the YOURx-Terminal to be removed by loosening a wing nut. Includes the top bracket, plate, wing nut and screws. Applications: Pole mount, wall mount, pedestal mount (minimum 10" (254.00 mm) pedestal) or vault mount.



Pre-Configured Part Numbers

Part Number	Description
018123	Kit, Top Mount Bracket, YOURx-Terminal

Bottom Mount Bracket Kit for YOURx-Terminal

Description

Terminal is bolted to bracket from the bottom. Terminal is accessed by removing the cover. Includes the bracket and screws. Applications: Pole mount, wall mount, pedestal mount (minimum 10" (254.00 mm) pedestal) or vault mount.



Pre-Configured Part Numbers

Part Number	Description
018249	Kit, Pole/Wall Mount Bracket, YOURx-Terminal

Aerial/Strand Mounting Kit for YOURx-Terminal

Description

Bracket mounts to strand with two clamps. Terminal is accessed by removing the cover. Includes the top bracket, bottom bracket with wire cable support, lanyard and screws. Applications: Aerial/strand mount.






Pre-Configured Part Numbers

Part Number	Description
018456	Kit, Aerial/Strand Bracket for YOURx-Terminal, includes clamps, screws and lanyard

YOURx FlexPort —————

Description

Individual YOURx FlexPort for securing 10 mm or 14 mm microduct into the YOURx-Terminal or YOURx-TAP. Includes the outer coupler, inner housing and O-ring.



Pre-Configured Part Numbers

Part Number	Description
016280	YOURx FlexPort, push to connect, 10 mm
018107	YOURx FlexPort, push to connect, 14 mm
FSX-10MM EXPANSION KIT	Bag of four 10 mm YOURx FlexPorts and 10 mm FlexPort Plugs



YOURx-Terminal Accessories-



Slack Storage Reel for YOURx-Terminal -

Description

Reel is stored on the inside of the YOURx-Terminal, between the base and the FlexCartridge™. The reel will hold up to 10 feet (254.00 mm) of FieldShield® fiber slack.



Pre-Configured Part Numbers

Part Number	Description
FSTX-SLACK-REEL	Real, slack storage for YOURx-Terminal, holds 10 feed of FieldShield

YOURx FlexPort Filler Plug -

Description

YOURx FlexPort Filler Plug for 10 mm or 14 mm ports into the YOURx-Terminal or YOURx-TAP. Application: Used for sealing YOURx FlexPort holes if plug on the inside is removed.





Pre-Configured Part Numbers

Part Number	Description
018664	YOURx FlexPort Plug, filler for 10 mm cartridges
018665	YOURx FlexPort Plug, filler for 14 mm cartridges

YOURx Expansion Repair Kit ————

Description

Used to expand or add-drop feeder ports for YOURx-Terminal or YOURx-TAP.

Pre-Configured Part Numbers

Part Number	Description
FSX-EXPANSION REPAIR KIT	Expansion, Repair Kit for YOURx-Terminal and YOURx-TAP, Includes four 10 mm YOURx FlexPorts, four 10 mm YOURx FlexPort Plugs, one 14 mm YOURx FlexPort and one 14 mm YOURx FlexPort Plug

YOURx Pulling Tool —



Pre-Configured Part Numbers

(Part Number	Description
	FS-PUL-YOURX	Pulling tool for 10mm FieldShield FlexPort. Maximum pulling force 50 lb.
	FS-PUL-YOURX-14MM	Pulling tool for 14mm FieldShield FlexPort. Maximum pulling force 50 lb.

www.SeeClearfield.com 1-800-422-2537





FieldShield Field Installable FlexConnector -

Description

For field installed applications, these three kits allow a water-tight transition from 3mm and 4mm cable, into the FieldShield FlexPort. The kits include enough parts for six tool-less installations.



Pre-Configured Part Numbers

Part Number	Description
FS-FIFC-103-6PAK	Field installable FlexConnector, 10 mm Port, 3 mm Cable, Black Grommet, 6 Pack
FS-FIFC-143-6PAK	Field installable FlexConnector, 14 mm Port, 3 mm Cable, Gray Grommet, 6 Pack
FS-FIFC-144-6PAK	Field installable FlexConnector, 14 mm Port, 4 mm Cable, Red Grommet, 6 Pack

YOURx Removal Tool —————



Pre-Configured Part Numbers

Part Number	Description
FS-FLEXPORT-REMOVAL- TOOL-10	Tool for removing YOURx Breakout from FlexPort in 10 pack

www.SeeClearfield.com 1-800-422-2537