

### Top Mount Bracket Kit for YOURx-Terminal

#### Description

Bracket mounts to cover, allowing the YOURx-Terminal to be removed by loosening a wing nut. Includes the top bracket, plate, wing nut and screws. Applications: Pole mount, wall mount, pedestal mount (minimum 10" (254.00 mm) pedestal) or vault mount.



#### Pre-Configured Part Numbers

Part Number	Description
018123	Kit, Top Mount Bracket, YOURx-Terminal

### Bottom Mount Bracket Kit for YOURx-Terminal

#### Description

Terminal is bolted to bracket from the bottom. Terminal is accessed by removing the cover. Includes the bracket and screws. Applications: Pole mount, wall mount, pedestal mount (minimum 10" (254.00 mm) pedestal) or vault mount.




#### Pre-Configured Part Numbers

Part Number	Description
018249	Kit, Pole/Wall Mount Bracket, YOURx-Terminal

### Aerial/Strand Mounting Kit for YOURx-Terminal

#### Description

Bracket mounts to strand with two clamps. Terminal is accessed by removing the cover. Includes the top bracket, bottom bracket with wire cable support, lanyard and screws. Applications: Aerial/strand mount.




#### Pre-Configured Part Numbers

Part Number	Description
018456	Kit, Aerial/Strand Bracket for YOURx-Terminal, includes clamps, screws and lanyard

### YOURx FlexPort

#### Description

Individual YOURx FlexPort for securing 10 mm or 14 mm microduct into the YOURx-Terminal or YOURx-TAP. Includes the outer coupler, inner housing and O-ring.



#### Pre-Configured Part Numbers

Part Number	Description
016280	YOURx FlexPort, push to connect, 10 mm
018107	YOURx FlexPort, push to connect, 14 mm
FSX-10MM EXPANSION KIT	Bag of four 10 mm YOURx FlexPorts and 10 mm FlexPort Plugs